

ACcess Series

User Manual

Teleste Corporation



AC3200

Intelligent broadband amplifier

Contents

Introduction	3
AC3200 generations	4
Installation	5
Housing.....	5
Powering.....	6
Interfaces	6
Transponder	7
Front panel.....	8
Features	9
Diplex, input and output modules	9
Forward path.....	11
Return path	17
Remote communication	21
Establishing connection	22
Alarms.....	23
Led usage	25
Product key activation of advanced features.....	26
Transferring AC3200 settings	26
Updating AC3200 software.....	27
Updating transponder software	27
SNMP MIBs	28
Viewer pages	29
Status viewer page	30
Forward path viewer page	32
Return path viewer page	35
Transponder viewer page (CATVIsor).....	37
Transponder viewer page (HMS)	39
Transponder viewer page (DOCSIS).....	41
Monitoring viewer page	42
Spectrum viewer page	45
Ingress viewer page.....	48
Properties viewer page.....	50
Legal declarations	51

Introduction

AC3200 is a broadband amplifier with extended frequency and gain ranges in both forward and return paths. Thanks to the integrated electrical controls and microcontroller based control system all adjustments can be made automatically without signal interruption.

The amplifier features two high performance RF outputs with individual signal controls. The second high level output can be divided in two with a splitter or tap. The platform and accessories of AC3200 are fully functional up to 1 GHz.

True plug-and-play

An intelligent automatic alignment system with wide gain control range ensures optimum operation of the AC3200 amplifier. It replaces conventional mechanical plug-in module adjustments and laborious control of parameters. All the adjustments are electrical and controlled via the management interface. Plug-in attenuators or equalisers are not needed.

Local configuration of AC3200 is done via its USB interface using a PC or PDA equipped with CATVisor Commander software.

AC6990 / AC6991 / AC6980 transponder unit

AC3200 amplifier can be monitored and controlled remotely via optional plug-in transponder unit, which also adds ALSC with fully user programmable pilots and both forward and return path monitoring functionality. AC6990 supports forward path measurement up to 862 MHz, AC6991 and AC6980 up to 1000 MHz.

AC6990 and AC6991 support CATVisor and HMS protocols. AC6980 supports DOCSIS protocol. Remote monitoring and control is possible with CATVisor tools or with 3rd party SNMP management applications.

AC3200 feature map	Without transponder	With transponder
Intelligent continuous adjustments	•	•
Automatic SNR optimisation	•	•
Local control through USB connection	•	•
Remote monitoring and control	-	•
ALSC with fully user programmable pilots	-	•
Automatic return path alignment	•	•
Automatic forward and return path alignment with single pushbutton ¹⁾	-	•
Forward path spectrum analyser ¹⁾	-	•
Return path signal quality monitoring with automatic ingress control and filtering ¹⁾	-	•
Return path pilot generator ¹⁾	-	• ²⁾

1) These features need to be enabled with a Product Key.

2) AC6980 DOCSIS transponder does not support pilot generator.

Table 1. AC3200 feature map

AC3200 generations

There are three AC3200 generations with some differences in hardware and/or software functionality:

1st generation AC3200:

- Manufactured until Q2/2012
- No support for signal feed-through between input and bypass port when unpowered.
- No forward path plug-in disabling via software.
- Output 2 gain offset adjustable between -10...+10 dB.

2nd generation AC3200:

- Manufactured Q1/2012...Q4/2014
- Supports signal feed-through between input and bypass port when unpowered.
- Supports forward path plug-in disabling via software.
- Output 2 gain offset adjustable between -10...+10 dB.

3rd generation AC3200:

- Manufacturing started Q3/2014
- Supports signal feed-through between input and bypass port when unpowered.
- Supports forward path plug-in disabling via software.
- Output 2 gain offset adjustable between -8...+8 dB.

The generation information is visible in "Properties" viewer page.

Installation

Housing

The AC3200 can be installed either into a street cabinet or to the outdoor environment. The amplifier should be installed vertically so that the external cable connectors and ventilation hole are underneath, securing the housing with three mounting brackets. Figure 1 depicts for the positions of mounting brackets as well as other installation dimensions.

The cover opens with the hinges to the left. The open cover can be removed by first opening the cover into a 90 degrees angle and the lifting it off the hinges.

Before closing the lid is should be checked that:

- nothing is trapped between the lid and the case
- all case gaskets are in their correct positions
- lid seats evenly on the rubber gasket

The lid retaining bolts should be tightened to 3 Nm torque in a diagonal sequence. The class of enclosure is IP54 when correctly installed and tightened.

Amplifier housing should be grounded with at least 4 mm² grounding wire (Cu) from a proper earth to the grounding point.

8607038




Figure 1. AC3200 housing dimensions – top side view

Powering

The supply voltage of the remote powered amplifier (27...65 V AC or $\pm 33...90$ V DC) can be fed through any of the cable connections by inserting a fuse to the corresponding fuse holder (Figure 6 position 19). When a cable connection is used for powering, the maximum supply current is 8.0 A.

The power intake of the remote powered amplifier may also be done externally via the cable feed-through located on the upper left corner of the amplifier. In this case the maximum supply current is 12.0 A.

External power can also be fed through the amplifier into the network. Maximum feed-through current is 8.0 A per port.

Interfaces




Figure 2. Port locations – bottom view

The AC3200 amplifier has four dedicated cable connection points: input, input bypass/output and two outputs. The amount and function of the actual connectors varies with the chosen configuration.

All coaxial outputs have a standard PG11 thread and they accept any KDC type adapter or connector. A suitable length of the coaxial cable inner conductor exposed for the connectors is approximately 20 mm (Figure 3).




Figure 3. Centre conductor length

Transponder

8612012




Figure 4. AC6991 transponder unit, 1) “Set” -button, 2) Fastening bolt, 3) Indicator for ALSC status , 4) Indicator for modem status, 5) Light sensor




Figure 5. AC6980 DOCSIS transponder unit, 1) “Set” -button, 2) Fastening bolt, 3) Indicator for ALSC status, 4) Indicator for DOCSIS status, 5) Remote management USB connector, 6) Light sensor

To install a transponder unit, first locate the correct installation position. Snap off the segments of the shrouds break-away type slot cover and remove the slot cover. Insert the unit by pressing it gently into place. The unit will fit only in one orientation. Finally tightly fasten the mounting bolt to ensure proper grounding and cooling, using flat screwdriver with AC6990/AC6991 transponders and 3 mm allen key with AC6980 transponder. There is no need to switch off the supply voltage during module installation.

The USB connector in AC6980 transponder front panel is reserved for remote management connection. Local management of the AC3200 unit should be done via motherboard USB connector.

Front panel

58800033




Figure 6. AC3200 front panel

- | | |
|--|---------------------------------|
| 1) Input | 11) Transponder slot |
| 2) Input by-pass / Output 3 | 12) Status led |
| 3) Output 2 | 13) USB port |
| 4) Output 1 | 14) Output 1 diplex filter |
| 5) Input module (see table 2) | 15) Output 2 diplex filter |
| 6) Input diplex filter | 16) Output 1 test point |
| 7) Input test point | 17) Output 2 test point |
| 8) Forward path universal plug-in | 18) Output module (see table 3) |
| 9) Return path universal plug-in | 19) Fuse(s) |
| 10) Forward path highpass filter plug-in | |

Features

Diplex, input and output modules

The AC3200 is delivered according to the specifications defined in the ordering code. Optional return path operation needs plug-in diplex filters (Figure 6, positions 6, 14 and 15). The available diplex filter types are CXF030 (30/47 MHz), CXF042 (42/54 MHz), CXF050 (50/70 MHz), CXF065 (65/85 MHz) and CXF085 (85/108 MHz). It is also possible to order the amplifier with no diplexers.

The "Frequency split" selection in user interface controls return path low pass filters. It has to be set to match the installed diplex filters and forward path high pass filter to ensure correct RF performance of the amplifier – see table 1. If the installed filters and "frequency split" selection do not match, amplifier RF performance may be severely deteriorated. The forward path high pass and return path low pass filters are factory installed according the chosen diplex filter configuration. Note! AC6242 forward path high pass filter is installed, if the amplifier is ordered with no diplex filters.

Diplex filter	Forward path high pass filter plug	Correct "Frequency split" selection
CXF030	AC6245	65/85 MHz
CXF042	AC6245	65/85 MHz
CXF050	AC6245	65/85 MHz
CXF065	AC6242	65/85 MHz
CXF085	AC6241	85/108 MHz

Table 2. Correct combinations for diplex filter, forward path high pass filter plug and "frequency split" selection to ensure correct RF performance

The forward path frequency range selection (862 MHz / 1 GHz) can be selected independently of AC3200 diplex filters or other hardware modules. It affects only forward path slope adjustment pivot point frequency and does not activate any kind of low-pass filtering etc.

Input and output modules are passive plug-ins used to control the outputs – see tables 2 and 3. During amplifier adjustment the plug-in unit positions for input and output modules must be equipped at least with the 0 dB modules.

Module	Functionality as input module	Input	Bypass
AC6110	0 dB input module, no by-pass	0 dB	not used
AC6112	1/12 dB tap, by-pass in use	-12 dB	-1 dB
AC6116	1/16 dB tap, by-pass in use	-16 dB	-1 dB
AC6119	1/20 dB tap, by-pass in use	-20 dB	-1 dB
AC6124	Two-way splitter, by-pass in use	-4 dB	-4 dB
AC6128	2/9 dB tap, by-pass in use	-9 dB	-2 dB

Table 3. Input modules with corresponding nominal attenuation values

Module	Functionality as output module	Output 2	Output 3
AC6120	0 dB output module, 2 outputs in use	0 dB	not used
AC6112	1/12 dB tap, 3 outputs in use	-1 dB	-12 dB
AC6116	1/16 dB tap, 3 outputs in use	-1 dB	-16 dB
AC6119	1/20 dB tap, 3 outputs in use	-1 dB	-20 dB
AC6124	Two-way splitter, 3 outputs in use	-4 dB	-4 dB
AC6128	2/9 dB tap, 3 outputs in use	-2 dB	-9 dB

Table 4. Output modules with corresponding nominal attenuation values

Installed output module controls how amplifier bypass / output 3 (Figure 6 position 2) port is configured. When output module slot is equipped with AC6120 module, this port is input bypass port. When output module slot is equipped with a tap or splitter module, this port is output 3 port. It should be noted that this slot can not be left empty.

2nd and 3rd generation AC3200 amplifiers (see "AC3200 generations" chapter) route signals between input port and input bypass port also when the amplifier is not powered, provided that the correct input and output modules are installed.

Forward path

The input and output amplifier stages are both based on high performance solutions which allow the user to set AC3200 outputs for trunk or distribution levels. The output stage uses a GaAs hybrid to improve RF performance over the entire 47 to 1000 MHz pass band.

Forward path gain control

AC3200 has three gain control elements in its forward path signal route:

- 1) Input gain: equivalent to input plug-in attenuator in traditional amplifiers, adjustable in 1 dB steps between -20 and 0 dB, except for the missing -1 dB value.
- 2) Interstage gain: controls the output 1 interstage gain, adjustable in 0.2 dB steps between -15 and 0 dB.
- 3) Output 2 interstage gain: identical to output 1 interstage gain, adjusted via offset to output 1 interstage gain. Output 2 gain offset range is -10...+10 dB for 1st and 2nd generation and -8...+8 dB for 3rd generation AC3200.

The forward path gain control elements and thus the resulting total forward path gain can be controlled in three different adjustment modes:

- 1) Manual mode: All controls are available to the user with no restrictions, resulting output 1 total gain is shown. This mode should be used only if "intelligent manual" mode doesn't give wanted results, or gain fine-tuning is required.
- 2) Intelligent manual mode: Output 1 total gain can be adjusted by the user in 1 dB steps. Output 2 is adjusted with gain offset. Amplifier software uses the total gain value to adjust all three gain control elements so that amplifier performance is at its optimum with all gain settings. This is the factory default and recommended setting for normal adjustment.
- 3) ALSC mode, available with transponders: The amplifier software controls output 1 interstage gain and slope to keep the pilots is user specified levels. Output 2 interstage gain follows output 1 interstage gain with the user specified offset. Input gain control is available to the user.

Note that when a plug-in module is installed into forward path universal plug-in slot the displayed total gain value may be incorrect.

Forward path slope control

Forward path slope is controlled by three elements:

- 1) Input slope: adjustable between 0 and 20 dB in 1 dB steps.
- 2) Output 1 interstage slope: adjustable between 0 and 13 dB in 0.2 dB steps.
- 3) Output 2 interstage slope: identical to output 1 interstage slope, adjusted via offset to output 1 interstage slope.

Input slope control is available to the user regardless of the selected gain adjustment mode. Interstage slope is read-only in ALSC mode.

Forward path universal plug-in module

AC3200 has a universal plug-in slot in the forward path. If not used, the plug-in slot is automatically bypassed, i.e. no jumpers need to be installed.

Due to the wide gain and slope adjustment range of AC3200, cable simulator plug-in modules are usually not needed. The automatic alignment can adjust the amplifier forward path properly even with pre-sloped input signal.

The embedded software detects whether the plug-in is installed or not, but cannot detect installed plug-in type. If a plug-in module is installed, its type must be entered into the software for correct return path automatic alignment operation. If the plug-in type in the software does not match the installed plug-in module type, return path can be incorrectly aligned during automatic alignment.

When a plug-in module is installed into forward path universal plug-in slot the displayed total gain value may be incorrect. Plug-in module gain and slope are taken into account during forward path automatic alignment so that AC3200 performance is always optimised.

2nd and 3rd generation AC3200 amplifiers support disabling an installed forward path plug-in module via user interface. Thus it is possible, for example, to always install a cable simulator module and enable it only when needed.

Plug-in module types known by AC3200 software:

- **None:** No plug in. If automatic alignment is started and a plug-in is detected, automatic alignment stops and gives "Unknown plug-in" error.
- **Other:** Plug-in is assumed to be a 0 dB jumper and thus automatic alignment may adjust return path incorrectly.
- **Cable simulators:** TXS802, TXS804, TXS808
- **Equalisers** (for 606 MHz operation): TXE605, TXE602
- **Attenuators** (with high frequency peaking): TDA802, TDA804

ALSC

AC3200 uses the transponder RF level measurement unit to sequentially measure signal levels of output 1 at user defined frequencies and, if enabled, also the forward path spectrum and return path ingress frequencies. If ALSC adjustments are needed more priority is given to pilot measurements.

ALSC (Automatic Level and Slope Control) keeps the output 1 signal level stable irrespective of input signal level variations by adjusting the interstage gain and slope controls based on the pilots. Gain and slope are adjusted slowly in small steps to guarantee stable operation in long amplifier cascades. If output 1 interstage gain or slope is adjusted against the limit, AC3200 gives "ALSC saturated" alarm and stops adjusting.

Output 2 follows output 1, i.e. interstage gain and slope controls are adjusted so that the user specified offsets to output 1 interstage gain and slope values remain unchanged. If output 2 interstage gain and/or slope is adjusted against the limit, AC3200 still continues to adjust output 1 but gives "ALSC saturated" alarm to indicate that output 2 can no longer follow output 1.

AC3200 has both high and low pilots and reserve pilots for both. The high pilot controls interstage gain and the low pilot controls interstage slope. Input gain and slope are not controlled by ALSC. Pilot target levels for all four pilots can be independently configured by the user.

If a pilot is lost, i.e. its level falls below "Lost level", AC3200 uses the respective reserve pilot for ALSC and gives "ALSC main pilot(s) missing" alarm.

If both high main and high reserve or both low main and low reserve pilots are lost, AC3200 gives "ALSC on 1 pilot only" alarm, freezes slope control and controls gain with the remaining pilot.

If all four pilots are lost, AC3200 gives "ALSC all pilots missing" alarm and, depending on user selection, either freezes gain and slope controls or slowly steps the controls to predefined values.

Pilot backoff and previous amplifier pilot target level settings are not used by ALSC, they are for forward and return path automatic alignment only.

Forward path automatic alignment

The forward path can be automatically aligned with a single pushbutton, provided that transponder is installed and the feature is enabled with correct Product Key. Correct main pilot settings and output 2 gain and slope offset values need to be programmed, either at the factory or by the user.

Automatic alignment can be activated with transponder front panel "Set" button, if it is enabled in software. This button also activates return path automatic alignment after forward path alignment has been successfully completed. It is also possible to activate forward or return path automatic alignment procedures separately via the user interface.

The automatic alignment adjusts the amplifier gain and slope settings so that pilot targets are reached while simultaneously optimising amplifier performance and making sure ALSC has enough adjustment range.

Total slope adjustment is divided between input and interstage controls based on pilot target level and backoff settings. The pilot backoff values need to be set for correct automatic alignment operation.

When forward path automatic alignment starts, "ALSC" led starts blinking in green. If the alignment completes successfully, the calculated gain/slope values are taken into use, ALSC is activated and the led returns to its normal status dictated by ALSC related flags, i.e. usually green. If some of the calculated gain/slope values cannot be reached but the error is less than 2 dB, the led flashes in yellow for a couple of seconds, the nearest possible values are taken into use and ALSC is activated. If the automatic alignment process stops due to an error, the led flashes in red for a couple of seconds, all controls return to their original values and ALSC is not activated.

If the automatic alignment is started with transponder "Set" button and forward path alignment completes successfully (or within the abovementioned 2 dB tolerance) then return path alignment is started.

Possible forward path automatic alignment error reasons and their explanations, which are displayed in the dialog box when the alignment is started via the user interface:

- "*Pilot target out of range*": Main pilot target levels are outside 80...120 dB μ V range, low pilot target level is above high pilot target level, or high and low pilots have less than 100 MHz between them.
- "*Pilot not found*": Measured high main or low main pilot level is below 75 dB μ V. Pilot frequency may be incorrect.
- "*Interstage slope out of range*": Calculated output 1 interstage slope is outside 1...11 dB range, leaving not enough room for ALSC adjustments.
- "*Interstage 2 slope out of range*": Calculated output 2 interstage slope is outside 1...11 dB range, leaving not enough room for ALSC adjustments.
- "*Input slope out of range*": Calculated input slope is outside input slope adjustment range.
- "*Gain out of range*": Calculated output 1 total gain is outside amplifier adjustment range.
- "*Gain 2 out of range*": Calculated output 2 total gain is outside amplifier adjustment range.




Figure 7. Simplified forward path automatic alignment flowchart

Spectrum analyser

AC3200 spectrum analyser can be used to measure and monitor output 1 forward path signals, provided that transponder is installed and the spectrum analyser feature is enabled with correct Product Key.

Up to 100 measurement frequencies with individual peak / average detector (for PAL / QAM signals, respectively) selection and high / low limits can be specified by the user.

The spectrum analyser uses the same tuner unit than ALSC pilot measuring and ingress analyser. Pilot measurements have higher priority, but when pilots are stable and no gain or slope adjustments are needed, spectrum and ingress analysers get more time, resulting in ~3...4 measurements/s speed.

Each measurement frequency can have both, either or no alarm limits. The measurement result is compared against its limits. When all frequencies have been measured the number of measurements exceeding their limits is compared to the "Tolerance" parameter and the "Spectrum out of limits" alarm status is updated. The "Tolerance" parameter can be used to fine-tune alarm sensitivity; default value 0 activates the alarm even if only one measurement result exceeds its limits.

Return path

AC3200 return path has exceptionally wide gain and slope adjustment ranges.

Return path gain and slope control

AC3200 adjusts its three gain control elements and one slope control element to achieve optimum return path performance based on the gain and slope value selected by the user.

Input 1 gain can be adjusted in 1 dB steps between 0 and 30 dB.

Input 2 gain is adjusted via offset to input 1 gain.

Slope is common for both inputs and can be adjusted in 1 dB steps between 0 and 10 dB.

Ingress control switches

Ingress control switches are independent for both inputs and can be used to attenuate return path or to cut it off completely. Ingress measurement and modem communication are not affected by ingress switch, thus it is possible to monitor incoming ingress and communicate with RF modem even when return path is cut off.

Ingress control switches can also be controlled automatically based on detected ingress, separately for each input. When automatic attenuation during ingress alarm is enabled, ingress control switch is disabled from the user and AC3200 software operates it between 0 dB and attenuated values.

When "Ingress alarm" alarm of an input is active for at least "activation delay" time, ingress control switch for that input will go to attenuated state. When "Ingress alarm" is not active for at least "deactivation delay" time, ingress control switch will return to 0 dB state.

Activation and deactivation delays are common for automatic ingress switching and automatic return path plug-in activation. They allow fine-tuning the operation and prevent unwanted switching on spurious signals. Note that ingress alarm status is only updated after each ingress measurement cycle.

The default attenuation value 6 dB can be adjusted separately for both inputs between 3 and 15 dB to further fine-tune the automatic ingress attenuation feature.

Return path automatic alignment

The return path automatic alignment is done after the user has pressed transponder front panel "Set" button and forward path automatic alignment has completed successfully. It is also possible to start return path automatic alignment via user interface, even when transponder is not installed.

Return path automatic alignment relies on forward path to be correctly aligned. The user can specify installed forward path plug-in module type and previous amplifier pilot target levels. When specified these are taken into account in return path automatic alignment. Otherwise it is assumed that previous amplifier's level and slope settings are identical to this one, i.e. all needed gain and slope adjustment is due to either cable losses or passive splitting of signal between amplifiers. The amount of cable and passive attenuation is calculated from forward path gain and slope values. Return path gain and slope values are then calculated from these values. Input 2 gain follows input 1 gain with the user specified offset.

Note that if the forward path automatic alignment cannot reach the calculated values but the error is less than 2 dB, the closest possible values are taken into

use and the resulting error may thus affect return path automatic alignment calculation.

When the return path automatic alignment completed successfully, the "ALSC" led blinks in green for a couple of seconds. If the operation fails, the led blinks in yellow for a couple of seconds.

Possible return path automatic alignment error reasons and their explanations:

- *"Unknown forward path plug-in"*: Software has detected a plug-in module in forward path slot but the user has specified the plug-in type as "None". Gain and slope are not adjusted. Correct plug-in type should be entered. Selection "Other" overrides the plug-in module checking and allows adjustment, but may result in gain and/or slope error.
- *"Pilot target out of range"*: Main pilot target levels or previous amplifier target levels are outside 80...120 dB μ V range. Gain and slope are not adjusted.
- *"Gain / slope saturated"*: Calculated input 1 gain and/or slope are outside amplifier's adjustment range. Gain and/or slope are both adjusted but optimal adjustment is not achieved.
- *"Gain 2 out of range"*: Calculated input 2 gain is outside adjustment range. Gain is adjusted but optimal adjustment is not achieved.

Return path automatic alignment adjusts gain and slope in 0.5 dB steps. User sees only values rounded to multiples of 1 dB. When gain or slope is adjusted manually after automatic alignment, the first adjustment step may be between 0.5-1.5 dB instead of normal 1 dB step.

Ingress analyser

AC3200 ingress analyser can be used to measure and monitor return path signals, provided that transponder is installed and the ingress analyser feature is enabled with correct Product Key.

Up to 30 measurement frequencies with individual peak / average detector (for signals / noise, respectively) selection and high warning / high alarm limits can be specified by the user. The measurement files containing frequencies, detector types and alarm limits can be specified separately for each input port. It is also possible to measure and monitor only one port.

The ingress analyser uses the same tuner unit than ALSC pilot measuring and spectrum analyser. Pilot measurements have higher priority, but when pilots are stable and no gain or slope adjustments are needed, spectrum and ingress analysers get more time, resulting in ~3...4 measurements/s speed.

Each measurement frequency can have both, either or no alarm limits. Each measurement result is compared against its limits. When all frequencies have been measured the number of measurements exceeding limit is compared to "Tolerance" parameter and "Ingress warning (2)" and "Ingress alarm (2)" statuses are updated. The "Tolerance" parameter can be used to fine-tune alarm sensitivity; default value 0 activates the alarm even if only one measurement result exceeds its limits.

When ingress is to be measured, measurement frequencies should be selected so that there are no other return path signals nearby. Selecting a measurement frequency close to other signals will affect the dynamic range of the ingress analyser.

Ingress analyser alarm can also be used to trigger automatic return path ingress switch attenuation, or automatic return path plug-in activation, or both.

Return path universal plug-in module

AC3200 has a universal plug-in slot in the return path, common for both inputs. This can be used for e.g. high pass filter to get rid of ingress. If not used, the plug-in slot is automatically bypassed, i.e. no jumpers are needed.

The embedded software detects whether the plug-in is installed or not, but cannot detect installed plug-in type. Thus displayed return path gain and slope values may be incorrect when a plug-in module is installed. The plug-in is not taken into account in return path automatic alignment.

All JDA series attenuators and filter plugs like AC6223 and AC6227 are supported by AC3200. Note however that there are some special plug-in modules in JDA mechanics which are not detected by AC3200 and thus are always bypassed. See plug-in specification for more details.

The user can control when return path plug-in is used through the UI:

- 1) Use if installed: the default mode, plug-in is always used if installed.
- 2) Never use: plug-in is always bypassed
- 3) Use if ingress alarm is active: plug-in is activated if "Ingress alarm" or "Ingress alarm 2" alarm is active. This feature can be used for e.g. activating a high pass filter automatically based on detected ingress. The ingress switch activation and deactivation delays are used as with automatic ingress switch operation; otherwise these two features are independent of each other. If transponder is not installed, the ingress alarm is never active and thus plug-in is always bypassed.

Plug-in module does not affect ingress measurement results and modem communication in any way.

Return path pilot generator

AC3200 return path pilot generator can be activated when transponder is installed and the feature is enabled with Product Key. It is supported by AC6990 and AC6991 transponders.

There can be up to 4 user programmable pilot frequencies in the frequency range of 5...65 MHz (0.1 MHz steps). Pilot levels are specified at the transponder output as with modem transmit levels, and restricted to 75...100 dB μ V range. The viewer displays resulting equivalent input level, i.e. the level at which a signal should be injected to return path input 1 to appear at equivalent level with the generated pilot signal at return path output.

When the pilot generator is enabled, AC3200 outputs one of the pilot signals for a user defined pilot duration, then switches to the next pilot signal and then repeats again. The pilot duration parameter is ignored if only one pilot signal is activated.

Possible RF modem transmissions occur asynchronously, i.e. in the middle of any pilot transmission. Pilot output is switched off during modem transmission and resumes after the modem transmission has been completed.

Pilot signals closer than 0.3 MHz from modem transmit frequency are not generated. Pilot signals can cause problems to modem communication if the pilot is close to modem frequency and pilot level is high compared to modem transmit level. Thus it is recommended to keep pilots at least 0.5 MHz from modem frequency.

Detection of these time domain multiplexed return path pilot signals can be accomplished at head end with e.g. a standard spectrum analyser instrument used in "Max hold" mode, or with another amplifier capable of return path signal measurement.

Remote communication

The transponder module is used for remote communication. Software version 3.0 and above supports AC6990, AC6991 and AC6980 transponders and CATVisor, HMS and DOCSIS communication protocols.

With AC6990 and AC6991 it is possible to set the communication protocol to CATVisor or HMS via the user interface. CATVisor protocol is compatible with Teleste CATVisor Commander and EMS system. HMS protocol uses SNMP for remote communication and can thus be used also with 3rd party management software. It is possible to change between CATVisor and HMS also remotely. All modem related settings should be carefully reviewed before changing the protocol to avoid loss of remote communication.

With AC6980 the remote communication protocol is SNMP. CATVisor protocol is also supported and thus e.g. CATVisor SmartLoader can be used.

The reported modem receive and transmit levels are measured at transponder RF input and output ports. The receive level is directly related to amplifier forward path output level. Transmit level vs. amplifier return path input level varies with return path gain as depicted in technical specification.

Transponder "Modem" led is dark while the unit is scanning for communication channel and blinks while it is establishing the communication link. During normal communication the led colour is decided from modem-related alarms.

CATVisor modem functionality

After reset the transponder starts scanning for HEC (HeadEnd Controller, e.g. Teleste HDM100 T) carrier within the user specified frequency range. When a communication channel is found, it waits for registration slot and sends its registration request. If the HEC accepts the registration, transponder enters normal communication mode where it is periodically polled by the HEC.

If the registration fails, or transponder is in normal communication mode but doesn't receive any packets from the HEC it starts scanning again. During registration the HEC sends communication parameters such as transmitter frequency and transmitter level.

All communication between the transponder and CATVisor Commander, EMS or SmartLoader is done with UDP/IP packets via the HEC. This means that transponder IP address has to be unique and match HEC's subnet settings.

HMS modem functionality

HMS mode is similar to CATVisor mode. The transponder scans for HMTS (Hybrid Management Termination System, e.g. Teleste HDM100 H) carrier. Transmit level is not set by the HMTS and thus has to be adjusted manually. In HMS the behaviour when forward communication is lost is controlled by the HMTS settings.

For details on HMS modem functionality, please refer to HMTS documentation and HMS standards.

DOCSIS modem functionality

AC6980 transponder acts as a standard DOCSIS 2.0 cable modem. It scans through the whole forward path band. There are no communication settings available for user, everything is done automatically as commanded by the CMTS (Cable Modem Termination System). Depending on the CMTS and headend LAN settings it is usually necessary to configure the transponder MAC address to DHCP server and allow SNMP (UDP ports 161 and 162) and CATVisor (UDP port 2500) traffic to transponders.

Establishing connection

All the needed configurations and adjustments can be carried out locally or remotely by using the CATVisor Commander software. Detailed CATVisor Commander hardware requirements and installation instructions can be found from the User Manual supplied with Commander.

Connection to AC3200 is possible using the following methods:

Local configuration with PC through standard USB port

Commander 2.7 or later is needed for USB support.

Connection to AC3200 USB port can be done with a standard USB A plug to USB mini B plug cable, or via AC6901 USB to Bluetooth adapter. The cable or adapter should be disconnected when not in use to avoid possible EMC problems caused by the cable acting as an antenna.

Windows may ask for USB driver when connecting to AC3200 via USB for the first time. If not found automatically, the driver can be found in 'C:\Program Files\Common\Teleste\Drivers', select 'telestecdc.inf' file. During the installation Windows may ask if it should stop the installation because the installation file is not signed. Select 'Continue Anyway'.

AC3200 will draw power from the USB connector for its microcontroller and memory if no external power supply is available. This makes it possible to configure AC3200 settings and update the software without any power supply.

Note that as only the CPU part of the unit is powered via USB and many parameters visible via the user interface may display incorrect values. Installing and removing plug-in modules while the unit is USB powered is not recommended and may lead to unexpected behaviour.

The USB connector in AC6980 transponder front panel is reserved for remote management connection.

Remote CATVisor connection

Remote IP connection via a HEC (e.g. Teleste HDM100 T) with AC6990/AC6991 transponder. Transponder IP address has to be correctly set before remote IP communication is possible. It has to match the subnet settings of the HEC's HFC network interface and it must also be unique for each transponder.

Note that it is also possible to set the IP address remotely via the HEC, see HEC documentation for details.

Remote HMS connection

Remote SNMP connection via a HMTS (e.g. Teleste HDM100 H) with AC6990/AC6991 transponder. AC3200 can be accessed remotely using an SNMP Manager application. Usually there is no need to pre-configure any communication parameters to establish connection with the HMTS. However, the selected installation procedure may include presetting e.g. the IP address, transmit level and the forward path frequency scanning limits.

Remote DOCSIS connection

Remote SNMP connection via a CMTS with AC6980 transponder. AC3200 can be accessed remotely using an SNMP Manager application. The CMTS system must be preconfigured to accept the transponder and the used protocols.

Alarms

The module alarms, also known as "flags", displayed in CATVisor Commander and EMS are described in the table below. Equivalent SNMP traps are also available via remote connection with HMS and DOCSIS protocols.

The affected led and factory default severity settings are presented next to each alarm in Table 5. All alarm severities (Major / Minor / Notification / Disabled) and alarm limits can be fully configured by the user. See the 'Monitoring' chapter for more details.

Note that some alarm limits (e.g. remote AC supply voltage) are factory configured so that alarms will only appear when hardware specifications are exceeded. The alarm limits should be reconfigured to match network parameters if more precise monitoring is needed.

Alarm text	Description & suggested corrective action	Led	Default severity
Temperature high	Temperature is above high limit.	Station	Major & Minor
Temperature low	Temperature is below low limit.	Station	Minor
AC voltage high	AC voltage is above high limit.	Station	Minor
AC voltage low	AC voltage is below low limit. As some units are equipped with mains power supply, this alarm is disabled as factory default and should be enabled by the user if AC voltage is to be monitored.	Station	Disabled
+24V voltage high	+24V voltage is above high limit.	Station	Major & Minor
+24V voltage low	+24V voltage is below low limit.	Station	Major & Minor
+12V voltage high	+12V voltage is above high limit.	Station	Major & Minor
+12V voltage low	+12V voltage is below low limit.	Station	Major & Minor
Unknown module	Device is not able to recognize other module(s). Possible reason is old embedded software or bad installation of the transponder. If the embedded software is up to date and removing and reinstalling the transponder doesn't help, it should be sent to service.	Station	Major
Internal error	Device has an internal error. If resetting the unit does not help, it should be sent to service.	Station	Major
Lid open	Transponder's light sensor level has been above limit during last minute. Generated only if transponder is installed.	Station	Notification
Return path off	Return path is turned off by user.	Station	Notification
Return path attenuated	Return path is attenuated, either by user or automatically due to ingress.	Station	Notification
Settings changed	Unit's settings have been modified by user during last minute.	Station	Notification
Application started	Unit was reset or rebooted during last minute.	Station	Notification
Service terminal connected	There has been activity on local USB connector during last minute.	Station	Notification
Modem receive level low	RF modem receive level is too low for reliable communication. Generated only if transponder is communicating. Not generated with AC6980 DOCSIS transponder.	Modem	Minor
Modem not connected	RF modem is not communicating. Generated only if transponder is installed.	Modem	Notification
Modem transmit level saturated	Commanded transmit level is outside range. RF modem transmit level is saturated at minimum or maximum value. Generated only if transponder is communicating and minimum < maximum. Not generated with AC6980 DOCSIS transponder.	Modem	Notification
Tuner module error	Internal error in transponder's level measurement unit. May be due to out-of-range measurement frequencies. If resetting the unit doesn't help, it should be sent to service. Generated only if transponder is installed	Station	Major

ALSC all pilots missing	All pilots are missing. Generated only if transponder is installed and ALSC is enabled	ALSC	Major
ALSC saturated	ALSC is saturated, i.e. gain or slope adjustment limits have been reached. Generated only if transponder is installed and ALSC is enabled.	ALSC	Minor
ALSC on 1 pilot only	Upper/lower main and backup pilots are missing, ALSC is controlling gain only, and slope control is frozen. Generated only if transponder is installed and ALSC is enabled.	ALSC	Minor
ALSC main pilot(s) missing	One or both main pilot(s) are missing; ALSC uses backup pilot(s). Generated only if transponder is installed and ALSC is enabled.	ALSC	Notification
ALSC off	Transponder is installed but ALSC is switched off by user. Or ALSC is switched on by user but transponder is missing	ALSC	Notification
Spectrum out of limits	Spectrum analyser measurement results are not within high/low limits.	Station	Minor
Ingress 1 warning	Return path ingress measurement results of port 1 are above warning limits but below alarm limits.	Station	Minor
Ingress 1 alarm	Return path ingress measurement results of port 1 are above alarm limits.	Station	Major
Powered from USB	Processor powered from USB, rest of motherboard not alive.	Station	Notification
Ingress 2 warning	Return path ingress measurement results of port 2 are above warning limits but below alarm limits.	Station	Minor
Ingress 2 alarm	Return path ingress measurement results of port 2 are above alarm limits.	Station	Major

Table 5. AC3200 alarms in CATVisor / HMS

Led usage

Modem related alarms are indicated with transponder "Modem" led, ALSC related alarms are indicated with transponder "ALSC" led, other alarms are indicated with AC3200's "Status" led. The affected led and factory default severity settings are presented next to each alarm in Table 5. Alarms with "notification" severity do not affect leds.

ALSC led	Description
 red	ALSC enabled, ≥1 major alarm
 yellow	ALSC enabled, ≥1 minor alarm
 green	ALSC enabled, no alarms
 green blink	Automatic alignment running
 yellow blink	Automatic alignment targets not fully achieved
 red blink	Automatic alignment stopped due to an error
 dark	ALSC off

Modem led	Description
 red	Modem connected, ≥1 major alarm
 yellow	Modem connected, ≥1 minor alarm
 green	Modem connected, no alarms
 green blink	Modem registering
 dark	Modem not connected

Status led	Description
 red	≥1 major alarm (other than modem / ALSC)
 yellow	≥1 minor alarm (other than modem / ALSC)
 green	No alarms
 red blink	Software cannot start
 dark	Software / CPU / power failure

Product key activation of advanced features

Some AC3200 software features need to be activated with correct product key:

- Automatic forward and return path alignment
- Forward path spectrum analyser
- Return path ingress analyser with automatic ingress control and filtering
- Return path pilot generator

The activation can be done when ordering the product and also later by contacting Teleste support. CATVisor Commander user manual provides more details on entering the product key.

Transferring AC3200 settings

All user accessible settings are stored on the motherboard memory. Thus plug-in modules can be changed without losing any settings.

A "Settings Saver" DLL component for AC3200 is included in the latest DUS100 viewer packet release. It can be used with CATVisor Commander and CATVisor SmartLoader to transfer partial or complete device settings between a file and AC3200. This feature can be accessed through Commander > "Tools" > "Load/Save element configuration" when it has been activated with correct serial number. SmartLoader supports also transferring settings from/to multiple units simultaneously.

Note that the Settings Saver component uses CATVisor protocol and cannot thus be used remotely with HMS communication protocol.

The settings are stored as *.ECML files in XML format. These files can be also edited with standard text editors, provided that the XML tags and structure are maintained. Tags can be removed to create partial settings files. This makes it easy to download e.g. new pilot target levels to multiple units simultaneously.

The settings saver ECML files can also be edited in user-friendly format with an Excel tool. This tool can be downloaded from Teleste Club. The settings saver ECML files can also be used for specifying factory settings when ordering preconfigured AC3200 amplifiers.

AC3200 will draw power from the USB connector for its microcontroller and memory if no external power supply is available. This makes it possible to configure AC3200 settings and update the software without any power supply.

Note that as only the CPU part of the unit is powered via USB, many parameters visible via the user interface may display incorrect values. Installing and removing plug-in modules while the unit is USB powered may lead to unexpected behaviour.

Downloading device settings containing modem parameters over remote connection may cause loss of remote connection. Thus some settings may be not written correctly. If modem parameters need to be written, it is recommended to put them into a separate ECML file which is downloaded after other settings.

Updating AC3200 software

New software versions for AC3200 are published at Teleste Club. These may contain bug fixes, enhancements and completely new features. For details see "AC3200 software release history" document also available in the Club.

AC3200 software can be updated locally via USB using CATVisor Commander or remotely via modem connection using CATVisor Commander or SmartLoader or 3rd party download tool. AC3200 stays fully operational during the update, i.e. RF paths are not affected, ALSC continues to operate etc. During the update no other communication except software update is replied, so the management system may report the AC3200 as missing during the update.

The new software is taken into use after it has been completely downloaded and the device is reset. The reset takes a couple of seconds after which the device is fully functional and running the new software. If the download fails, AC3200 continues to use its previous software.

For CATVisor updates the same file is used for both local and remote update.

For remote SNMP update a different file must be used.

Local update

AC3200 software can be updated locally via USB using CATVisor Commander. Local software update of AC3200 takes ~1 minute.

AC3200 will draw power from the USB connector for its microcontroller and memory if no external power supply is available. This makes it possible to configure AC3200 settings and update the software without any power supply.

Remote update – CATVisor protocol

Remote update for CATVisor is done using CATVisor Commander or SmartLoader. It is also possible to download new software to multiple devices simultaneously without resetting them and take the new software into use later by sending a broadcast reset with CATVisor SmartLoader.

Remote update – HMS protocol

Remote update for HMS is done using SNMP protocol according to the standard HMS-DOWNLOAD-MIB. Special software tools are available for this purpose. Please refer to the documentation of the specific tool in use.

Remote update – DOCSIS protocol

AC3200 software can be updated remotely with either CATVisor or HMS protocols as described above.

Updating transponder software

AC6991 and AC6980 transponders have their own tuner software which handles the pilot / spectrum / ingress measurements. The tuner software can be updated locally or remotely by using the methods above.

When the tuner software transfer has completed, it can take up to 1 minute for the transponder software to be updated by AC3200. Wait until the new software version appears in the user interface before removing power or the transponder.

AC6980 transponder DOCSIS software update

AC6980 transponder has its own DOCSIS software which handles the remote communication. This software is updated by using the standard DOCSIS methods, i.e. TFTP file download initiated by DHCP server configuration.

SNMP MIBs

The parameters of a unit in HMS or DOCSIS mode can be accessed remotely using SNMP MIBs (Management Information Base). Should they be needed for e.g. integration with 3rd part management systems, the Teleste-proprietary MIBs are available for download in Teleste Club. SCTE MIBs can be downloaded from SCTE website.

Supported MIBs for AC product family:

- RFC1213-MIB
- SNMPv2-MIB
- TELESTE-ROOT-MIB
- TELESTE-ACX-MIB
- TELESTE-COMMON-MIB
- TELESTE-HE-STATUS-MIB
- TELESTE-HMSMODEM-MIB
- TELESTE-ANALYSER-MIB
- TELESTE-PILOTGENERATOR-MIB
- TELESTE-ALARMS-MIB
- SCTE-HMS-PROPERTY-MIB
- SCTE-HMS-ALARMS-MIB
- SCTE-HMS-COMMON-MIB
- SCTE-HMS-FIBERNODE-MIB
- SCTE-HMS-DOWNLOAD-MIB

Viewer pages

This chapter presents AC3200 viewer pages used with local or remote CATVisor protocol connection. The viewer pages used with SNMP remote connection with HMS or DOCSIS protocols slightly different in layout but contain all the same parameters.

The viewer pages used to control AC3200 using CATVisor Commander or EMS are explained in this chapter. For a complete description of each feature, see corresponding "Features" chapter.

Some features may be greyed out, indicating that they can not be used at the moment due to e.g. missing plug-in module.

AC3200 viewer pages in CATVisor Commander / EMS:

- Status
- Forward path
- Return path
- Transponder (different pages for CATVisor / HMS / DOCSIS)
- Monitoring
- Spectrum
- Ingress
- Properties

Some viewer pages have fields with coloured background, e.g. "Temperature" on "Status" page. These colours indicate the alarms related to this field. Green means no alarms or notifications; red is major alarm, yellow is minor alarm and blue is notification.

Status viewer page




Figure 8. The Status page

The Status page displays unit's alarm list together with measurement data and a graphical view of the current configuration similar to the actual station layout.

Alarm list

Each alarm in the alarm list on the bottom left corner is colour coded according to its severity. The severities can be configured through "Monitoring" viewer page. For additional information about alarms, see table of module alarm descriptions in the "Alarms" chapter.

Station layout

The transponder is detected automatically and represented as grey box. Some modules and plugs, e.g. fuses, cannot be detected automatically. These are presented with blue texts. Selecting a text tag representing a passive device will open a pull down selection list in which an appropriate device according the assembly can be selected. The user can also type in the desired information (up to 12 characters, 6 characters for fuses).

The forward path universal plug selection is used by the return path automatic alignment and should be set according to the installed plug-in module. Otherwise the information entered in these fields does not affect unit operation in any way, it's just a "checklist".

See "Features" chapter for details on plug-in modules and configuration.

Measurements

The background colour of each field shows the parameter's alarm status. Alarm limits and severities can be configured through "Monitoring" page.

AC3200's internal temperature is displayed in top-left field next to layout view.

Lid status information is based on a light sensor in the transponder's front panel. "Lid open" is displayed if light level has been above limit during the last minute. In dark environment "Lid closed" may be displayed even if the lid is open. "Lid unknown" indicates that the transponder is not installed.

The "Service terminal" field shows whether there has been activity on the local USB service connector during the last minute.

The "Supply voltages" frame displays measured supply voltages of the station.

The "AC voltage" field shows true RMS value (DC+AC component) of the remote supply voltage. This value is calculated using sliding average and thus reacts quite slowly to changes. The factory default limit values are based on AC3200's power supply specifications and are thus quite broad. They should be adjusted to match the network's AC supply voltages if accurate monitoring is needed.

+12 V and +24 V factory default alarm limits are based on power supply specifications and usually shouldn't be altered.

Amplifier operation mode

The "Forward path" selection should be set to match the network's upper frequency limit (862 MHz / 1 GHz). It affects only forward path slope adjustment pivot point frequency and does not activate any kind of low-pass filtering etc.

The "Frequency split" selection controls return path low pass filters. It has to be set to match the installed diplex filters and forward path high pass filter plug to ensure correct RF performance of the amplifier – see Table 2. If the installed diplexers and "frequency split" selection do not match, amplifier RF performance may be severely deteriorated. The default value is 65/85 MHz.

AC3200 selects input bypass / output 3 port mode automatically based on the plug-in module installed into "Output module" slot. The status of the port is displayed in "Port 3" status field and in station layout picture.

Transponder front panel has a "Set" button which starts automatic alignment for both forward and return paths. The button can be disabled to prevent accidental presses by clearing the "Enable transponder button" checkbox.

Notes

The "Notes" field allows storing up to 100 character message into AC3200 non-volatile memory. It can be used e.g. as a reminder for the pilot settings.

Forward path viewer page

Pilot name	Frequency (MHz)	Type	Backoff (dB)	Measured (dBµV)	Target (dBµV)	Calc. input (dBµV)	Usage
High main	610.00	QAM	0	102.0	102.0	94.9	ALSC
High reserve	650.00	QAM	0	101.2	102.0	93.7	Standby
Low main	121.00	QAM	0	98.0	98.0	97.7	ALSC
Low reserve	121.00	QAM	0	98.0	98.0	97.7	Standby

Figure 9. The Forward path page

The Forward path page displays all settings related to forward path adjustment. See “Forward path” chapter for details on forward path, ALSC and automatic alignment.

Gain, slope and total gain adjustment

Gain and slope controls can be adjusted by clicking the up and down buttons, dragging the sliders or typing a value into the fields. The availability of these controls depends on the selected adjustment mode. Output 2 automatically follows output 1 changes with the offset values specified in the “Interstage” frame. The resulting interstage gain and slope for output 2 are shown as read-only information with green background when the value is within adjustment range and with yellow background when the adjustment has saturated.

Adjustment mode

The “Adjustment mode” selects between:

- **ALSC:** Interstage gain and slope are controlled by ALSC. ALSC only measures output 1. Output 2 follows output 1 changes with the offset values. Input gain and slope can be adjusted by the user. Total gain is displayed.
- **Intelligent manual:** Total gain can be adjusted in 1 dB steps. Input gain, interstage gain and gain mode are automatically adjusted based on selected total gain to achieve optimum amplifier performance. Both slope controls can be adjusted in 1 dB steps.
- **Manual:** All gain and slope controls can be adjusted in 1 dB steps, except interstage controls in 0.2 dB steps. Total gain is displayed.

The data field displays the ALSC status:

- "ALSC on": ALSC is enabled and works properly.
- "ALSC off": ALSC is disabled by user.
- "ALSC saturated": ALSC is saturated (=adjustments limits reached), interstage 1 and/or 2 gain and/or slope are adjusted to limit.
- "ALSC main pilot(s) missing": One or both main pilot(s) are missing. ALSC uses reserve pilot(s).
- "ALSC on pilot 1 only": Upper or lower main and reserve pilots are missing. ALSC controls only gain and slope control is frozen.
- "ALSC all pilots missing": All four pilots are missing. ALSC is frozen or using "go to" values.
- "No transponder": No transponder unit installed. ALSC is disabled.
- "Tuner module error": Error in transponder tuner module. ALSC is disabled.

Automatic alignment

Clicking the "Align forward path" button will start forward path automatic alignment, provided that transponder is installed and the automatic alignment feature is enabled with correct Product Key. A dialog box is opened which displays the status of the alignment.

Universal plug

The "Universal plug" field shows whether there is a plug installed into forward path universal plug-in slot or not. The plug-in module type is not recognised by the software. The "Status" page can be used to select the installed plug-in. This information is needed for correct return path automatic alignment operation.

Starting from 2nd generation AC3200 amplifiers support disabling an installed forward path plug-in module with the "Disable plug" checkbox. Thus it is possible to e.g. install a cable simulator module and activate it only if needed.

Pilot table

If transponder is installed, each pilot measurement is shown in the table with the following information:

Pilot name: Icon and pilot name colour coding indicates pilot status:  green for pilot OK,  red for pilot lost.

Frequency (MHz): Pilot signal frequency, adjustable in 0.25 MHz steps. If 0 MHz is entered as pilot frequency, the pilot is disabled and thus it is not used in adjustment and no alarms of missing pilot are generated.

Type: Detector type. The measurement detector can be individually selected for each frequency to be either peak detect ("Analog") or averaging ("QAM").

Backoff (dB): Pilot signal backoff for automatic alignment operation.

Measured (dBµV): Measured level of pilot signal.

Target (dBµV): Pilot signal target level for ALSC operation.

Calc.input (dBµV): Calculated pilot level at amplifier input. The calculation is based on measured level, gain and slope settings, forward path bandwidth and installed known universal plug-in modules and assumes AC6110 (0 dB) input module. The value is only informative with no accuracy specification.

Usage: Display which pilot(s) are used by ALSC

The pilot frequency, detector type, backoff and target level can be edited by double-clicking a row in pilot table. This will open a dialog box (Figure 10) with pilot's properties that can be edited with at least "Service" level user rights.

The following parameters are available in addition to the pilot table parameters:

Lost level: Limit below which the pilot is considered as lost.

Previous amplifier target level: Pilot target level at the amplifier feeding forward path signal to this amplifier. Displayed for main pilots only. Used by return path automatic alignment, by default identical to target level.




Figure 10. The pilot signal configuration dialog box

All pilots lost action

When all pilots are lost, AC3200 gives "ALSC all pilots missing" alarm and operates as selected by "All pilots lost action" radio buttons:

- Freeze controls: Interstage gain and slope controls will keep the values they had immediately before the pilot signals were lost.
- Go to: Interstage gain and slope controls will slowly step to user defined values in the "Gain" and "Slope" edit fields.

Return path viewer page




Figure 11. The Return path page

The Return path page displays all settings related to return path adjustment. See “Return path” chapter for details on return path and ingress control.

Gain and slope

The "Gain 1 / Gain 2" and "Slope" fields, sliders and up and down buttons can be used to control the return path gain and slope values in 1 dB steps.

Input 2 gain automatically follows input 1 gain changes with the offset value specified. The resulting input 2 gain is shown as read-only information with green background when the value is within adjustment range and with yellow background when the adjustment has saturated.

The return path automatic alignment can be started independently of forward path automatic alignment by clicking “Align return path automatically” button, even when transponder is not installed.

Ingress switches

The radio buttons are used to control the behaviour of ingress switches.. The “-50 dB” selection cuts off the incoming return path RF signal and thus disconnects all transponders behind this amplifier, but the AC3200 itself can still measure return path ingress and communicate with its modem.

The ingress switch attenuation value can be adjusted between 3...15 dB. This can be used to fine-tune the automatic ingress attenuation feature.

Automatic ingress blocking

The Ingress measurement status is displayed on the top of the frame:

- "Ingress OK": Ingress measurement results are within limits.
- "Ingress warning": Ingress measurement results are above warning limits.
- "Ingress alarm": Ingress measurement results are above alarm limits.
- "Ingress analyser off": Analyser is disabled by user.
- "No transponder": No transponder module installed.

- "Tuner module error": Error in transponder tuner module.

When "Attenuate during ingress alarm" checkbox is selected, ingress switches are controlled by AC3200 based on "Ingress alarm" / "Ingress alarm 2" status and activation and deactivation delays. The activation and deactivation delays can be used to fine-tune this feature.

Return path plug

Plug-in use can be selected from three choices:

- Use if installed: the default mode, plug-in is always used if installed.
- Never use: plug-in is always bypassed
- Use if ingress alarm is active: plug-in is activated only if "Ingress alarm" or "Ingress alarm 2" alarm is active. The ingress switch activation and deactivation delays are used as with automatic ingress switch operation; otherwise these two features are independent of each other.

The plug-in status is shown on the right of this selection.

Pilot generator

The "Pilot generator" frame is active when AC6990 or AC6991 transponder is installed and the pilot generator feature is enabled with correct Product Key

The "Enable pilot generator" checkbox is the master switch for return path pilot generator. When the pilot generator is enabled, AC3200 outputs one of the pilot signals for a user defined "Pilot duration", then switches to the next pilot signal and then repeats again. The "RF modem Tx frequency" data field shows as read-only information the used transmitter frequency commanded by the HEC.

Pilot frequency, level and enabling can be controlled for all four pilots separately. Equivalent input level is shown next to each pilot. It takes into account return path losses, gain setting and ingress switch setting. When ingress switch is set to "Off" the equivalent input level is not valid and shown as "N/A".

Transponder viewer page (CATVisor)

This page is visible with AC6990 / AC6991 transponder in CATVisor mode.

The screenshot shows the 'Transponder' tab selected in a software interface. The 'Connection status' is 'Connected (11)'. The 'Receiver' section shows Frequency: 85.3 MHz, Level: 67 dBµV, Scan start: 85.0 MHz, Scan stop: 87.0 MHz, and Scan step: 0.1 MHz. The 'Transmitter' section shows Frequency: 15.0 MHz, Level: 85 dBµV, Min level: 75 dBµV, and Max level: 100 dBµV. The 'Tx level at return path input' section shows Input 1: 63 dBµV, Input 2: 63 dBµV, Input 3: N/A dBµV, and Input 4: N/A dBµV. The 'Communication settings' section shows IP address: 10.9.88.4, Net mask: 255.255.255.0, and MAC address: 009050031716. The 'Device group' section shows checkboxes for devices 1 through 8, all of which are checked. The 'Packet statistics' section shows Received: 64132, Bad: 0, and Sent: 64130, with a 'Reset' button. The 'Communication protocol' section shows 'CATVisor' selected and 'HMS' unselected.

Figure 12. The Transponder (CATVisor) page

The “Transponder” page displays all the data and settings of the transponder’s RF modem and remote communication. See “Remote communication” chapter for details.

Connection status

The current communication status between the transponder and HEC is shown in the “Connection status” field with

- “Scanning: searching for the HEC carrier.
- “Data carrier found”: waiting for communication parameters.
- “Registering”: registration in progress.
- “Connected”: registration complete, communication OK.

The number in parenthesis is a more detailed status indicator for diagnostics purposes, ranging from 0 to 11.

Receiver

The “Frequency” data field shows the used receiver frequency.

The “Level” data field shows the measured signal level.

The “Scan start” and “Scan stop” fields determine the frequency band that the unit scans through when searching for the HEC carrier. Scanning can be disabled by setting the start and stop frequencies to the same value. Scanning speed can be improved by limiting the scanning range. The default and maximum range is 80...155 MHz. The scan will start from the last known HEC carrier frequency.

The “Scan step” field sets the frequency increments of the scanning process, default and minimum value is 0.1 MHz.

Changing any of these fields will reset RF modem communication.

Transmitter

The "Frequency" data field shows the used transmitter frequency commanded by the HEC. The "Level" data field shows the transmitter signal level.

The range for transmit signal level can be set in the "Min level" and "Max level" fields. The default range is 75...100 dB μ V and maximum range is 75...104 dB μ V. If the HEC commands transponder to use transmit level outside this range, nearest allowed value is used and "Modem transmit level saturated" alarm is activated.

Changes in these values will not reset RF modem communication and will be taken into use immediately if HEC's ALC is enabled.

Tx level at return path input

These fields show the calculated equivalent input level for the transponder transmit level. This is the signal level that needs to be injected to return path input to appear at return path output at same level than transponder signal.

Communication settings

The "IP address" field is used to define the IP address of the unit. The address has to be unique and match the HEC's IP subnet settings to ensure proper operation and IP level communication with the HEC.

If the IP address is set incorrectly, e.g. 0.0.0.0, the transponder can still communicate with the HEC on MAC level, but IP traffic (i.e. viewer / EMS messages) is not possible. It is possible to set the IP remotely via the HEC.

The "Net mask" field defines the corresponding IP subnet. It is only needed for broadcast software updates and has to be set according to the HFC subnet of the HEC; otherwise it can be left as 255.255.255.255.

The "MAC address" is the unit's unique, read-only hardware address that is also printed on the transponder front panel sticker.

Manageable devices in the same HFC network can be divided into different device groups. The "Device group" check boxes can be used to group transponders under multiple HECs. For more information, consult HEC user manual.

Changing any of these fields will reset RF modem communication.

Packet statistics

The "Received" field displays the total number of IP packets addressed to and received by this unit.

The "Sent" field displays the total number of IP packets sent by this unit.

The "Bad" field displays the number of all bad packets received and is a good indicator of the forward path condition.

Packet counters wrap around at 65535, so absolute values are not meaningful.

The "Reset" button will reset all packet counters to zero.

Communication protocol

It is possible to change between CATVisor and HMS on the fly. Careful planning is needed in e.g. HEC / HMTS setup for successful change, especially over remote connection. Changing the setting and clicking "Apply" will open a dialog for entering parameters specific for the selected protocol. After accepting the values the unit will reset and start communication using the new protocol.

Transponder viewer page (HMS)

This page is visible with AC6990 / AC6991 transponder in HMS mode.




Figure 13. The Transponder (HMS) page.

The " **Connection status** ", " **Receiver** ", " **Transmitter** ", " **Packet statistics** ", " **Tx level at return path input** " and " **Communication protocol** " frames are the same as in the CATVisor version of this page and are described in the preceding chapter. However, HMS standard does not support automatic transmit level alignment and therefore the transmit level is manually adjusted in the HMS version.

IP address

This is the transponder's IP address. In HMS the this field is just a storage place. Depending on the used addressing method, the HMTS may or may not use this value. It may also change this value using MAC layer commands.

MAC

Unicast MAC: The transponder's globally unique MAC layer address.

Multicast MAC: The transponder supports up to four (4) multicast addresses that can be used for setting parameters in groups of devices. Note that not all HMTS's support multicast.

CHNLDESC timeout: HMTS broadcasts periodically the CHNLDESC datagram that informs the transponders about data channel frequencies. This timeout defines how long the transponder waits for an eventual CHNLDESC datagram, to define whether the carrier is an HMS channel. After the transponder is registered, it uses a timeout twice as long as the set value, to avoid the transponder from leaving the channel in case the reception of one CHNLDESC is unsuccessful. The HMTS should be set to broadcast CHNLDESC 0.5...0.9 x CHNLDESC timeout.

Poll timeout: If the transponder receives no datagrams to its own MAC address, it will wait up to this timeout, before declaring itself as 'forgotten' by the HMTS. After this timeout expires, the transponder will start reregistration.

"Period", "Ack timeout", "Retries", "Kmin", "Kmax": These values are used by the backoff calculation algorithm, in case a collision happens in the return path transmission (two or more transponders transmitting simultaneously). These values are for experts only and should be changed only in very special cases. The default 'Period' value is 60 ms.

SNMP communities

SNMPv1 community strings. The transponder will only accept SNMP GET/GET NEXT commands containing the Read or Write community string and SET commands containing the Write community string. Traps are sent containing the Trap community string. Communities can be adjusted **only locally**.

SNMP traps

Enabled: Enables/disables sending of HMS SNMP traps.

Delay: The time to wait before sending an HMS alarm trap, once an alarm is detected. This parameter can be used to control trap storms in amplifier cascades. By setting a longer delay deeper in the cascade, traps can be set to arrive on due order.

Interval: The minimum time between successive traps. This parameter applies only if several alarms are detected simultaneously.

Lifetime: The time the transponder keeps an HMS alarm trap in the transmit queue, if it cannot be sent for some reason (controlled by HMTS).

All trap parameters are adjustable also remotely via TELESTE-COMMON-MIB. Teleste MIBs are available at Teleste Club.

Transponder viewer page (DOCSIS)

This page is visible with AC6980 transponder.




Figure 14. The Transponder (DOCSIS) page

The “Transponder” page with AC6980 transponder displays read-only status information on the DOCSIS communication. See “Remote communication” chapter for details.

Connection status

The current communication status between the transponder and CMTS is shown in the “Connection status” field. The number in parenthesis is a more detailed status indicator for diagnostics purposes, ranging from 1 to 13.

Receiver

The used forward path frequency, receive level at transponder input and modulation are shown in respective fields. "S/N ratio" is the measured signal to noise ratio at DOCSIS receiver.

Transmitter

The return path frequency, transmit level at transponder output, channel ID and bandwidth are shown in respective fields.

DOCSIS module

The current time and public IP address obtained from CMTS are shown in respective fields together with DOCSIS module hardware version, serial number and software version. DOCSIS module software can be updated only remotely via CMTS (DHCP/TFTP).

The local IP addresses are shown for reference only.

The MAC address is the unit’s unique, read-only hardware address that is also printed on the transponder front panel sticker.

The "Reset DOCSIS" button forces the module to re-establish the communication link.

Monitoring viewer page




Figure 15. The Monitoring page

The "Monitoring" page displays all monitored parameters and their values as well as alarm limits, statuses and severity settings.

See "Alarms" chapter for descriptions of individual AC3200 alarms.

Analog parameters

Each monitored analog parameter of the unit is displayed in the upper half of the frame with following information in the list:

- Analog parameter:** Name of the monitored parameter.
- Alarm:** Alarm status of the parameter: No / HIHI / HI / LO / LOLO
- Value:** Current measured value.
- HIHI:** High major alarm limit
- HI:** High minor alarm limit.
- LO:** Low minor alarm limit
- LOLO:** Low major alarm limit.
- Deadband:** Specifies how much the measured value has to be on the "safe" side of alarm limit before turning off the alarm.
- Unit:** Unit of the measured parameter.

The colour of each list entry and the icon next to parameter name indicate alarm status:

- green for nominal value
- red for major alarm
- yellow for minor alarm
- grey for disabled alarm

The alarm settings are user configurable by double-clicking an analog parameter. This will open a dialog box with parameter's alarm limits and deadband that can be edited by users with at least "Service" level user rights. For others this is read-only information.




Figure 16. The analog alarm configuration dialog box

Each alarm limit can be individually enabled/disabled and configured. The alarm limits should be in decreasing order for correct alarm processing, preferably with more than "Deadband" units between each limit.

Discrete parameters

Each monitored discrete parameter of the unit is displayed in the lower half of the frame with following information in the list:

Discrete parameter: Name of the monitored parameter.

Alarm: Alarm status of the parameter: No / Notification / Minor / Major. If the alarm is disabled, but parameter is in alarming state, "Yes" is shown.

Setting: Alarm severity can be configured to Major, Minor, Notification or Disabled.

The colour of each list entry and the icon next to parameter name indicate alarm status:

- green for nominal value
- red for major alarm
- yellow for minor alarm
- blue for notification
- grey for disabled alarm

The alarm severity setting is user configurable by double-clicking a discrete parameter. This will open a dialog box which can be edited by users with at least "Service" level user rights. For others this is read-only information.



Figure 17. The discrete alarm configuration dialog box

Alarm control

Alarm control frame provides independent on-delay and off-delay timers. The time delay feature can be used to eliminate false alarm triggering due to momentary disturbances. An alarm is only active when "Detection" is enabled and the monitored parameter has been over limit longer than "Delay On" time.

Alarm goes off when the parameter has been inside limits longer than "Delay Off" time.

The settings on the "Alarm control" frame can be edited by a user with at least Service level user rights. For others this is read-only information. It is recommended not to change these values from their factory default value 1 s without fully understanding the effects on EMS system performance.

Alarm log

Clicking the "Alarm log" button on "Monitoring" page opens alarm log dialog.




Figure 18. The Alarm log dialog

The "Alarm log" dialog box displays the alarm history for latest 32 events. The list is stored in non-volatile memory. All entries are date and time stamped with the most current entry at the bottom. Note that date/time information may not be correct for events that occurred before latest reset.

The icon and colour of each list entry indicate alarm status:

- green for nominal value
- red for a major alarm
- yellow for a minor alarm
- blue for a notification

The total number of entries in the alarm log list is shown in the "Number of entries" field. The index number of the last entry is displayed in the accompanying field. Total number of entries is limited to 32. The oldest entry is overwritten when the log becomes full.

To update "Alarm log" page, click the "Refresh" button.

"Clear and regenerate log" button clears alarm log and restarts alarm detection.

Spectrum viewer page




Figure 19. The Spectrum page

When the spectrum analyser feature is enabled with correct Product Key, the "Spectrum" viewer page presents forward path level measurements in a graphical "spectrum analyser" display. Up to 100 measurement frequencies with individual peak / average detector selection and alarm limits can be specified with a simple text file. The measurement results can be saved back to a text file.

Display settings

When the viewer page is opened, the measurement results are retrieved from the device and displayed. The display can be zoomed or re-centred by entering new values into start and stop frequency, reference level and scale dialogs and clicking "Redraw" button. The "Fit view" button scales the display so that all measurement frequencies are visible; "Reset view" button restores full-scale display.

The RBW (resolution bandwidth) is fixed by transponder HW and depends on the installed transponder type, see transponder spec sheet.

The "Sweep" field displays the last elapsed time it took to scan through the complete set of measurement frequencies.

The "View levels" drop-down box can be used to select the plotted data:

- "Output": Displays the measured levels at amplifier output.
- "Calc.input": Displays the calculated signal levels in amplifier input. These values are based on measured levels at amplifier output and amplifier gain and slope settings. The calculation includes selected forward path bandwidth and installed known universal plug-in modules and assumes AC6110 (0 dB) input module. Due to the nature of the calculation and multiple possible error sources, the value is only informative with no accuracy specification.
- "X dB de-sloped": Simulates a view of a flat frequency response by reducing the level at the high end of the amplifier's response. Signal level at maximum

forward path frequency is displayed with the attenuation specified in "De-sloped view", signal level at 47 MHz is not affected at all and attenuation of the frequencies between these two are calculated using a standard coaxial cable model. The "De-sloped view" function acts only as a visual aid for making adjustments.

If the graphical display is clicked with mouse the frequency, measured level, detector mode and possible alarm limit values of the clicked measurement are displayed next to the clicked point.

Limits

When "Show" is checked the alarm limits for each measurement frequency are shown in the graphical display with blue triangles for low limit and red triangles for high limit. If a measurement is over high limit it will be drawn in red; in blue if it is below low limit; otherwise in black.

The "Tolerance" field specifies how many measurements are allowed to be outside limits before the "Spectrum out of limits" alarm is generated. The default value 0 will generate the alarm even if only one value is outside limits. "Tolerance" allows fine-tuning the limit testing so that e.g. it doesn't react to one missing TV channel. The alarm is set or cleared at the end of each measurement cycle.

Analyser settings

The "Analyser on" is the master switch for spectrum analyser feature.

The data field next to "Analyser ON" check box displays the ingress status: Spectrum OK / Spectrum out of limits / Spectrum analyser off.

The "Restart sweep" button clears the measurement results table and restarts the sweep. The "Current sweep file" field displays the first 15 characters of the filename of the last sweep file downloaded to the device.

The "File >> Device" and "Device >> File" buttons open a file dialog for transferring a sweep / result file to / from the device.

Sweep and result file formats

The sweep file is a simple text file than can be edited with any text editor and most spreadsheet applications. Each line in the sweep file defines one measurement frequency, preferably in ascending order. Each line has 2-4 fields separated with tab characters and dot (.) as the decimal separator:

1. The measurement frequency in multiples of 0.25 MHz.
- 2: The detector mode as "P" or "PAL" for peak detection or "Q" or "QAM" for averaging measurement. Detector mode designation is not case sensitive.
- 3: Optional low limit in multiples of 0.5 dB μ V.
- 4: Optional high limit in multiples of 0.5 dB μ V.

Comments can be inserted at the end of the line, preceded with a tab character, or on a separate row which starts with a non-numeric character. Comments are for information only and will not be downloaded into the device and so they are lost if result table is uploaded back from device.

An example of a valid sweep file:

```
113      QAM      98.0      103.5      Channel S2
121.00   Q          101       Channel S3
126.25   P          Another comment
133.25   PAL      95
```

The result file format is identical to the sweep file format, except that it has a header row and a 5th column which contains the measurement results. An example of a result file produced by the above sweep file could be like this:

MHz	Type	LoLimit	HiLimit	dB μ V
113.00	Q	98.0	103.5	100.5
121.00	Q		101	99.5
126.25	P			101
133.25	P	95		98

Ingress viewer page




Figure 20. The Ingress page

When the ingress analyser feature is enabled with correct Product Key, the "Ingress" viewer page presents return path level measurements in a graphical "spectrum analyser" display. Up to 30 measurement frequencies with individual signal / noise detector selection and alarm limits can be specified with a simple text file. The measurement results can be saved back to a text file.

Display settings

When the viewer page is opened, the measurement results are retrieved from the device and displayed. The display can be zoomed or re-centred by entering new values into start and stop frequency, reference level and scale dialogs and clicking "Redraw" button. The "Fit view" button scales the display so that all measurement frequencies are visible; "Reset view" button restores full-scale display.

The "Input" radio button selects the displayed return path input. The ingress measurement file, tolerance and all display settings are individual for each channel, but the ingress analyser main switch is common for both inputs.

The RBW (resolution bandwidth) is fixed by transponder HW and depends on the installed transponder type, see transponder spec sheet. Note that due to the roll off of the RBW filter, a payload-free area is needed if noise levels are to be measured.

The "Sweep" field displays the last elapsed time it took to scan through the complete set of measurement frequencies.

If the graphical display is clicked with mouse the frequency, measured level, detector mode and possible alarm limit values of the clicked measurement are displayed next to the clicked point.

Limits

When "Show" is checked the alarm limits for each measurement frequency are shown in the graphical display with red triangles for alarm limit and blue triangles for warning limit. If a measurement is over alarm limit it will be drawn in red; in blue if it is over warning limit but not over alarm limit; otherwise in black.

The "Tolerance" field specifies how many measurements are allowed to be over limits before the "Ingress warning" or "Ingress alarm" alarm is generated. The default value 0 will generate alarm even if only one value is outside limits. The alarms are set or cleared at the end of each measurement cycle.

Analyser settings

The "Analyser on" is the master switch for ingress analyser feature.

The data field next to "Analyser ON" check box displays the ingress status: Ingress OK / Ingress alarm / Ingress warning / Ingress analyser off.

The "Restart sweep" button clears the measurement results table and restarts the sweep. The "Current sweep file" field displays the first 15 characters of the filename of the last sweep file downloaded to the device for selected input.

The "File >> Device" and "Device >> File" buttons open a file dialog for transferring a sweep / result file to / from the device. Files for each input are transferred separately.

Sweep and result file formats

The sweep file is a simple text file than can be edited with any text editor and most spreadsheet applications. Each line in the sweep file defines one measurement frequency, preferably in ascending order. Each line has 2-4 fields separated with tab characters and dot (.) as the decimal separator:

- 1. The measurement frequency in multiples of 0.25 MHz.
- 2: The detector mode as "P" or "PAL" for peak detection of return path payload signals or "Q" or "QAM" for averaging measurement of return path ingress noise. Detector mode designation is not case sensitive.
- 3: Optional warning limit in multiples of 0.5 dBµV.
- 4: Optional alarm limit is in multiples of 0.5 dBµV.

Comments can be inserted at the end of the line, preceded with a tab character, or on a separate row which starts with a non-numeric character. Comments are for information only and will not be downloaded into the device and so they are lost if result table is uploaded back from device.

An example of a valid sweep file:

```
Measures return path lowest frequencies
5.00    Q        35.0    40.0    Comment
7.50    Q        35.0    40.0    Another comment
10.00   Q        35.0    40.0
12.50   Q        35.0    40.0
```

The result file format is identical to the sweep file format, except that it has a header row and a 5th column which contains the measurement results. An example of a result file produced by the above sweep file could be like this:

MHz	Type	HiLimit	HIHILimit	dBµV
5.00	Q	35.0	40.0	48.0
7.50	Q	35.0	40.0	49.0
10.00	Q	35.0	40.0	44.5
12.50	Q	35.0	40.0	44.0

Properties viewer page

The screenshot shows the 'Properties' tab selected in a software interface. The 'Identification' section includes text boxes for 'Name' (Amplifier 1), 'Location' (Verkakyla 1), and 'Contact' (Sami Halen). The 'Coordinates' section has two input fields for latitude (60° 26.742') and longitude (22° 23.790'), with a 'Format' dropdown set to 'dd° mm.mmm''. The 'Properties' section is a table with two columns: 'Station' and 'Transponder'. The 'Advanced functions' section has four checkboxes, all of which are checked. The 'Statistics' section has three input fields: 'Uptime' (3 d 02:06:44), 'Total uptime' (1540 days), and 'Reset count' (5), along with a 'Save debug info' button.

Identification	
Name	Amplifier 1
Location	Verkakyla 1
Contact	Sami Halen
Coordinates	60° 26.742' N 22° 23.790' E Format dd° mm.mmm'

Properties		
	Station	Transponder
Type	AC3200 (1st gen)	AC6991
Hardware version	E1.0	A1.2
Serial number	KN05720826	KK05201203
Software version	3.0.3	2.0.2

Advanced functions	
Spectrum analyser	Enabled
Ingress analyser	Enabled
Automatic alignment	Enabled
Return pilot generator	Enabled

Statistics	
Uptime	3 d 02:06:44
Total uptime	1540 days
Reset count	5

Figure 21. The Properties page

The “Properties” page displays unit identification and statistics data.

Identification

A descriptive alias name for the station can be entered into the “Name” field, site location into “Location” field and contact information into “Contact” field. All these fields can contain up to 63 characters.

The geographical coordinates can be entered into respective latitude and longitude fields. The preferred format for the coordinates can be selected from the "Format" drop-down field. When entering coordinates, special characters (°/'") can be simply omitted.

Properties

The type (and generation, if applicable), hardware version, serial number and software version (if applicable) are shown for both station and transponder.

Advanced functions

The statuses of advanced functions associated with Product Key are shown. These fields only indicate that the function is possible in the software, but does not display whether correct transponder module is installed for that function.

Statistics

The “Uptime” field shows the time since the last reset or power up. The format is days, hours, minutes and seconds, with ± 5 s/day accuracy.

The "Total uptime" field shows the total number of full operating days. The "Reset count" field shows the total number of resets.

The "Save debug info" button reads the unit's non-volatile memory contents and opens a dialog for saving it into "devicetype-serial-date.fun" and ".sad" files which can then be sent to Teleste support to help troubleshooting problems.

Legal declarations

Copyright © 2008 – 2014 Teleste Corporation. All rights reserved.

Teleste is a registered trademark of Teleste Corporation. Other product and service marks are property of their respective owners.

This document is protected by copyright laws. Unauthorized distribution or reproduction of this document is strictly prohibited.

Teleste reserves the right to make changes to any of the products described in this document without notice and all specifications are subject to change without notice. Current product specifications are stated in the latest versions of detailed product specifications.

To the maximum extent permitted by applicable law, under no circumstances shall Teleste be responsible for any loss of data or income or any special, incidental, consequential or indirect damages howsoever caused.

The contents of this document are provided "as is". Except as required by applicable law, no warranties of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability and fitness for a particular purpose, are made in relation to the accuracy, reliability or contents of this document.

Teleste reserves the right to revise this document or withdraw it at any time without notice.

WEEE Notice

This product complies with the relevant clauses of the European Directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE). The unit must be recycled or discarded according to applicable local and national regulations.



European Conformity

This equipment conforms to all applicable regulations and directives of European Union which concern it and has gone through relevant conformity assessment procedures.



Teleste Corporation
P.O. Box 323
FI-20101 Turku
FINLAND

www.teleste.com

TELESTE

www.teleste.com